

## 1.0 Prepare the recorder

Procedure:-

- 1.1 Download the unit to save any recorded data.
- 1.2 Hibernate the unit using LogTag Analyzer.

## 2.0 Remove old battery

Procedure:-


2.1 Carefully remove the rear label covering the battery door using a small-bladed screwdriver or knife.



2.2 Use a coin to turn the battery door anti-clockwise; remove it from case.



2.3 Remove the battery using a small-bladed screwdriver, as shown.



MicroDAO.com doc rev b, 27/12/2013

## 3.0 Insert new battery

## Only use batteries from a reputable manufacturer!

Procedure:-

3.1 Put a new replacement CR2032 cell into the battery compartment as shown below:

The right hand edge of the battery is inserted first against the contact.



Press firmly down on the left hand side of the battery to click the battery into place.



3.2 Replace the battery door; turn clockwise to lock it into place.



3.3 Cover the battery door with either a new label (Part # 100-000502) or reuse the old one.



3.4 Use LogTag Analyzer to configure the recorder.



Please dispose the old battery according to your local environmental regulations.

www.MicroDAQ.com

©Copyright 2009, LogTag<sup>®</sup> Recorders Ltd.

