

Lead Set, kWh Transducer to a Voltage Bus Bar (Part No: A-WNB-LEADSET)



DANGER!—HIGH VOLTAGE HAZARD



Making connections in an energized electrical enclosure or on any energized conductor can result in severe injury or death. This device should be installed by qualified personnel only. To avoid electrical shock, do not perform any installation or servicing unless you are qualified to do so. Disconnect and lock-out all power sources during installation and servicing. Please refer to applicable user manuals for instructions and use.

- For single-phase 120vac applications, red and blue leads are not used.
- For single-phase 208/240 applications, the blue lead is not used.
- For three-phase delta, no neutral applications, the white lead is not used.
- Remove alligator clips on unused leads for best practice.