

## **Instructions for 2.8K Type Ultra Low Temperature Sensor in Glass Bead Vial (FGD-0107-TEF)**

### **Instructions for Models 400, 800, 1400, 1800, 2800, and IMS-4210-E**

The probe may be connected to any available input terminal. Refer to your user's manual for configuration and programming. To connect the probe:

1. Remove any existing wiring or sensors (including local thermistor) from the input terminal.
2. Attach wire from the weatherproof temperature probe to the input terminal and ground respectively.

### **Instructions for WEB600, CELL682, Express II and Sentinel**

The probe may be connected to any available input terminal. Refer to your user's manual for configuration and programming. To connect the probe:

1. Remove any existing wiring or sensors from the input terminal.
2. Place the corresponding input shunt in the 'a' position for Express II.
3. Attach wire from the temperature probe to the input terminal and ground respectively.
4. Program the input type for a 2.8K thermistor in either Fahrenheit or Celsius.

**Warning: Do not submerge.**

© 2009 Sensaphone 901 Tryens Road, Aston, PA 19014

For Technical Support call 877-373-2700 or E-mail [support@sensaphone.com](mailto:support@sensaphone.com)

# 2.8K Type Ultra Low Temperature Sensor in Glass Bead Vial